



This documentation is for informational purposes only and subjected to change.

Always consult your dealer when you need help on tractor maintenance.

1. [Maintenance Check list](#)
2. [Diesel Fuel Specifications](#)
3. [Lubricants / Coolants](#)
4. [Replacement Parts](#)



Download the Tractor Service Kits overview

## 1. Maintenance Check list | Maintenance

Topic		Interval	▼: By user ●: By authorized YANMAR dealer or distributor													
			Service Intervals													
			Daily	If necessary	FIRST 50 hours	Every 50 hours	Every 250 hours	Every 500 hours	Every 1000 hours	Every 1500 hours	Every 2000 hours	Every 1 year	Every 2 years			
Engine Oil Level	Check	Daily	▼													
Transmission Hydraulic Oil Level	Check	Daily	▼													
Tire Air Pressure	Check	Daily	▼													
Grille	Check	Daily	▼													
Fuel Tank	Check/Refill	Daily	▼													
Rubber Dust Unloading Valve	Check	Daily	▼													
Radiator Hose and Clamp	Check	Daily   Every 500hr or 2 years *1	▼							●						●
	Replace	If necessary		●												
Radiator Cooling Screen	Check	Daily	▼													
Safety Systems	Check	Daily	▼													
Radiator Cooling Fins	Clean	Every 50 hr			●	▼										
Cooling System	Check	Daily	▼													
Coolant	Flush/Change	Every 2000hr or 2 years *1												●		●
Fuel Line	Check	Daily   Every 500hr or 2 years *1	▼							●						●
	Replace	If necessary		●												
Power Steering Line	Check	Daily   Every 500hr or 2 years *1	▼							●						●
	Replace	If necessary		●												
Seatbelt	Check	Daily   Every 500hr or 2 years *1	▼							●						●
	Replace	If necessary		●												
Roll-Over Protective Structure (ROPS)	Check	Daily   Every 500hr or 2 years *1	▼							●						●
	Replace	If necessary		●												
Headlights, Hazard Lights, and all other lights (lights and/or bulbs).	Check	Daily   Every 500hr or 2 years *1	▼							●						●
	Replace	If necessary		▼												
Fan and Alternator Belt	Inspect	Every 50 hr			●	▼										
	Adjust	50/250 hr and every 250hr after or every year *1			●		●									●
	Replace	If necessary		●												
Air Cleaner Element	Check/Clean	Every 250 hr and If necessary *3	▼					●								
	Replace	Every 500 hr or every year*1		●					●							●



This documentation is for informational purposes only and subjected to change.

Always consult your dealer when you need help on tractor maintenance.

1. [Maintenance Check list](#)
2. [Diesel Fuel Specifications](#)
3. [Lubricants / Coolants](#)
4. [Replacement Parts](#)



## 1. Maintenance Check list | Maintenance

Topic	Interval	▼: By user ●: By authorized YANMAR dealer or distributor													
		Service Intervals													
		Daily	If necessary	FISRT 50 hours	Every 50 hours	Every 250 hours	Every 500 hours	Every 1000 hours	Every 1500 hours	Every 2000 hours	Every 1 year	Every 2 years			
Fuses	Replace	If necessary	●												
Battery Condition	Check	Every 50hr			●	▼									
Fuel Filter	Replace	Every 500 hr or every 2 years *1							●						●
Fuel/Water Separator	Check	Daily	▼												
	Drain	Every 50 hr and if necessary		▼	●	▼									
	Replace	Every 500 hr or every 2 years *1							●						●
Wheel Bolt Tightening Torque	Check	After one hour of break -in *2 and every 50 hr   Every 250 hr or every 1 year *1			●	▼	●							●	
Engine Oil	Change	Every 250 hr or every year *1						●						●	
Engine Oil Filter	Replace	Every 250 hr or every year *1						●						●	
Transmission Hydraulic Oil	Change	50/500 hr and every 500hr after			●				●						
Transmission Hydraulic Oil Filter	Replace	50/500 hr and every 500hr after			●				●						
HST Hydraulic filter	Replace	50/500 hr and every 500hr after			●				●						
Hydraulic hose	Check	Daily   Every 500hr or 2 years *1	▼						●						●
	Replace	If necessary		●											
Grease fittings	Grease	Every 50 hr *4			●	▼									
Front Axle Pivot	Grease	Every 50hr *4			●	▼									
Air Intake Hoses and Clamps	Check	50/250 hr and every 250hr after or every year *1			●			●						●	
	Replace	If necessary		●											
Front Axle Gear Oil	Check	Every 50hr			●	▼									
	Change	Every 500hr							●						
Brake	Check	Daily	▼												
	Adjust	Every 500hr							●						
	Replace	If necessary		●											
Engine Valve Clearance *6	Adjust	Every 1000hr								●					
Fuel Injection Nozzle *6	Check	Every 1500hr									●				
Intake/exhaust valve seats *6	Clean	Every 2000hr										●			
Governor lever and engine speed control *6	Check and adjust	Every 250hr						●							
Crankcase breather system *6	Inspect	Every 1500hr									●				



This documentation is for informational purposes only and subjected to change.

Always consult your dealer when you need help on tractor maintenance.

1. [Maintenance Check list](#)
2. [Diesel Fuel Specifications](#)
3. [Lubricants / Coolants](#)
4. [Replacement Parts](#)



## 1. Maintenance Check list | CAB type & Attachments

Topic	Interval	▼: By user ●: By authorized YANMAR dealer or distributor												
		Service Intervals												
		Daily	If necessary	FIRST 50 hours	Every 50 hours	Every 250 hours	Every 500 hours	Every 1000 hours	Every 1500 hours	Every 2000 hours	Every 1 year	Every 2 years		
External air introduction filter	Clean	Every 250 hr and if necessary <sup>*3</sup>	▼		●									
	Replace	Every 500hr or 2 years <sup>*1</sup>					●							●
Warm water piping	Check	Every 500hr or 2 years <sup>*1</sup>					●							●
	Replace	If necessary		●										
Washer Liquid tank	Check / refill	Daily	▼											
Front Lift hydraulic lines. Check for leakages	Check	Daily   50/500 hr and every 500 hr after	▼		●		●							
Front lift	Grease	Every 50 hr			●									
Front Lift and front PTO bolts on torque	Check	50/500 hr and every 500 hr after or every 2years <sup>*1</sup>			●		●							●
Front PTO grease nipples	Grease	Every 500 hr					●							
Front PTO gear oil	Check	Every 250 hr				●								
	Replace	Every 500hr or every year <sup>*1</sup>					●						●	
Front PTO oil filter	Clean	Every 500hr or every year <sup>*1</sup>					●							●
	Replace	If necessary		●										
Drawbar	Grease	Every 50 hr			●	▼								
	Check	50/500 hr and every 500hr after			●		●							

<sup>\*1</sup> Whichever occurs first.

<sup>\*2</sup> Check the Wheel bolt Tightening torque after one hour of break -in.

<sup>\*3</sup> At Dusty Conditions: Clean filter once every 50 operating hours.

<sup>\*4</sup> Extremely Wet or Muddy Conditions: Lubricate the grease fittings once every 10 operating hours or once a day.

<sup>\*5</sup> For SA424 only.

<sup>\*6</sup> Dealer can find descriptions of this maintenance on YDS (Manual, Bulletin or Service News).



This documentation is for informational purposes only and subjected to change.

Always consult your dealer when you need help on tractor maintenance.

1. [Maintenance Check list](#)
2. [Diesel Fuel Specifications](#)
3. [Lubricants / Coolants](#)
4. [Replacement Parts](#)



## 2. Diesel Fuel Specifications

### 2.1. Diesel fuel regulation

Diesel fuel should comply with the EN590:96.

### 2.2. Additional technical fuel requirement

- Sulphur content not greater than 10 mg/kg (15 mg/kg at point of final distribution)
- Cetane number not less than 45

### 2.3. Bio-diesel fuel

In consistency with other global diesel engine manufacturers and diesel fuel injection equipment manufacturers, YANMAR encourages the development of renewable compression ignition fuels and wishes to clarify our position on the use of biodiesel fuels in YANMAR Industrial Engines.

Non-mineral oil based fuel resources such as RME (Rapeseed Methyl Ester) and SOME (Soybean Methyl Ester), collectively known as FAME (Fatty Acid Methyl Esters), are being used as extenders for mineral oil derived diesel fuels.

After YANMAR conducted the applicability evaluation, YANMAR approves the use of B7 (up to 7 % FAME) Diesel which shall not exceed a blend of 7 % (by volume) of FAME with 90 % (by volume) of approved mineral oil derived diesel fuel in YANMAR Industrial Engines.

YANMAR's limited warranty conditions in case certain engines manufactured by YANMAR are operated with B7 Diesel are as follows:

1. YANMAR accepts the use of B7 Diesel only on the conditions that B7 Diesel must comply with "the European standard EN14214 and EN590-2009 (for Oxidation stability)" in Europe.
2. Please purchase B7 Diesel only from recognized and authorized diesel fuel suppliers.
3. Please use only B7 Diesel including methanol as the above relevant regulations state; otherwise, it may cause corrosion in aluminum and zinc fuel injection equipment components.
4. Please use only B7 Diesel contained certain water level as the above relevant regulations state; otherwise, it may cause fuel filters plugged and also may increase bacterial growth.
5. Please use only B7 Diesel with low viscosity at high temperatures; otherwise, it may cause problems on fuel delivery, injection pump seizures and poor injection nozzle spray atomization.
6. Please check the engine oil level daily. If the oil level rises above the oil level of the previous day, the engine oil needs to be immediately replaced.
7. Please check and confirm the quality of B7 Diesel and other fuel tanks before you will start to use it. Please keep daily maintenance during the use of B7 Diesel and do not forget to regularly flush the fuel system and fuel storage containers. You may only use B7 Diesel at least within two (2) months from the time of filling the tank or three (3) months from the time of production by the said fuel suppliers, whichever comes first.

YANMAR does not warrant and is not responsible for any problems caused by the use of the deteriorated B7 Diesel or by the use of the B7 Diesel which do not comply with the above relevant regulations.

Consult your YANMAR tractor dealer before using the recommended biodiesel.

The engine of this machine uses precision parts in the fuel injection parts to comply with emission regulations. When storing fuel to be used, avoid using containers made of zinc plated steel sheet, but use resin or stainless metal containers. If the zinc or lead material melt into the fuel, it may cause engine malfunction.





This documentation is for informational purposes only and subjected to change.

Always consult your dealer when you need help on tractor maintenance.

1. [Maintenance Check list](#)
2. [Diesel Fuel Specifications](#)
3. [Lubricants / Coolants](#)
4. [Replacement Parts](#)



Download the Tractor Service Kits overview

### 3. Lubricants & coolants

No.	Locations / components	Capacities			Lubricants	
		Unit	SA221	SA424		
1.	Coolant*	L	CAB: 3.3 ROPS: 2.8		High Quality Permanent Type Antifreeze (Ethylene Glycol with corrosion and rust inhibitor chemicals) Coolant Mixture Ratio Distilled Water 50%: Antifreeze 50%	
2.	Engine oil - crankcase (with filter)	L	2.9	3.4	ACEA Service Categories E3, E4, or E5 SAE 10W-30, 15W-40	
3.	Transmission hydraulic oil	L	15.5		Hydraulic/Transmission Fluid (TF500A)	
4.	Front axle gear oil	L	3.0		SAE 80W-90 gear oil	
5.	Greasing	Tie rod	No. of greasing point	2	Until grease overflows	NLGI GRADE No.2
		Brake pedal	No. of greasing point	1	Until grease overflows	NLGI GRADE No.2
		HST pedal	No. of greasing point	1	Until grease overflows	NLGI GRADE No.2

(Specifications and design are subject to change without prior notice for improvement)

\*Immediately after purchasing the tractor:

- adjust the coolant mixture ratio of the coolant and water to suite the local climate
- the preceding practice assists in making the tractor function efficiently

The coolant can remain unchanged for a period of 2 years if during the period the tractor is operated for less than 2000 hours. If the tractor is operated for more than 2000 hours during the period, the coolant has to be replaced during flushing of the system. After pouring the coolant, run the engine for a short period to mix the two fluids thoroughly.

#### YANMAR GENUINE LUBRICANTS & COOLANTS

Type & Description	Change int. (h)		Size	Order no.
	SA221	SA424		
10W-30 Engine oil*	100	200	5 L	10W30-5L
			20 L	10W30-20L
			208 L	10W30-208L
15W-40 Engine oil*	100	200	1 L	15W40-1L
			5 L	15W40-5L
			20 L	15W40-20L
			208 L	15W40-208L
TF500A Transmission & hydraulic fluid*	600	600	20 L	TF500A-20L
80W90 Gear oil	500	500	1 L	80W90-1L
			20 L	80W90-20L
Grease-calcium	50	50	400 gr	GREASE-CALCIUM
Coolant**	1000/ 2 years	1000/ 2 years	1 L	COOLANT-1L
			5 L	COOLANT-5L
			20 L	COOLANT-20L
			208 L	COOLANT-208L

\*First lubricant change is at 50 hours \*\* Hours interval or time apply, whichever comes first



This documentation is for informational purposes only and subjected to change.

Always consult your dealer when you need help on tractor maintenance.

1. [Maintenance Check list](#)
2. [Diesel Fuel Specifications](#)
3. [Lubricants / Coolants](#)
4. [Replacement Parts](#)



## 4. Replacement parts

For a copy of the Illustrated Parts List or the Technical Manual of the tractor, contact your local YANMAR Tractor dealer. Only use the YANMAR authentic parts. Non-authentic parts can cause serious damage and accidents.

Item	Part Number	
	SA221	SA424
Engine Oil Filter		119305-35160
Transmission Hydraulic Oil Filter		198119-48310
HST Oil Filter		198167-24900
Air Cleaner Outer Filter		1A8330-05110
Fuel Filter Element		119810-55650
Alternator Belt	25152-003500	25152-003600
1 Amp Fuse		1A8426-52800
5 Amp Fuse		198535-52110
10 Amp Fuse		198535-52120
15 Amp Fuse		198535-52130
20 Amp Fuse		198535-52140
50 Amp Slow Blow Fuse		1E8720-83120
80 Amp Slow Blow Fuse		198153-51700
Battery		1A842E-51510
Headlights Bulb		1A8330-53250
Front Turn Signal Lights Bulb (CAB)		1A8060-53420
Front Turn Signal Lights Bulb (ROPS)		
Rear Turn Signal Lights Bulb (CAB)		1A7400-53530
Rear Turn Signal Lights Bulb (ROPS)		
Tail Lights Bulb (CAB)		1E9170-81270
Tail Lights Bulb (ROPS)		
Width Indicator Lamp Bulb (CAB)		1A8060-53410
Width Indicator Lamp Bulb (ROPS)		



## Easy service kit overview per tractor and maintenance interval

Order all the parts you need for the required maintenance intervals of your YANMAR tractor easy and fast with the Tractor Maintenance Kits overview.

- ✓ All required parts bundled in one box per interval
- ✓ Navigate to the desired maintenance interval with one click
- ✓ Easy ordering at your dealer using service kit numbers
- ✓ Clear overview of all maintenance intervals and required parts per tractor
- ✓ No need to search for the correct parts of your tractor. We have done it for you.

